

## **DIRECTIONS:**

SHAKE WELL BEFORE USING.

1. Clean both surfaces thoroughly.
2. Hold applicator perpendicular to substrate, 6-10 inches away.
3. Apply adhesive to one or both surfaces to be mated at 80-100% coverage. Spraying both surfaces will result in a stronger, more permanent bond.
4. Allow to dry until adhesive does not transfer to fingertips when touched before mating substrates.
5. Apply even pressure to ensure bond.

**AFTER USE: CLEAR VALVE OF ADHESIVE BY TURNING CAN UPSIDE DOWN AND SPRAYING FOR AT LEAST TWO SECONDS.**

**HI-TEMP SPRAY ADHESIVE IS RECOMMENDED FOR ALL APPLICATIONS REQUIRING EITHER HIGH STRENGTH OR HIGH TEMPERATURE, OR BOTH.** It is clear and non-yellowing. Use on trim work, headliners, door panels or other difficult applications. It is made for decorative laminate work in the furniture, cabinet or wood-working areas. This adhesive has web-type spray pattern. This product works well in marine applications to apply carpeting, insulation or other upholstery work and jobs found in van conversion, motor home and manufactured housing industries.

**LIMITATION OF REMEDIES AND LIABILITY** Use of this product represents acceptance of these terms. If these terms are not acceptable, return the product at once unused. If this product is proved defective, **THE EXCLUSIVE REMEDY AT MANUFACTURER'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT.** Manufacturer shall not otherwise be liable for loss or damage, whether direct, indirect, special, incidental, consequential or punitive, regardless of the legal basis asserted, including contract, tort, negligence, implied or express warranty or strict liability.

## **STORAGE & HANDLING**

USE ONLY IN WELL VENTILATED AREA.

Avoid contact with eyes, skin, and clothing.

Wash thoroughly after handling.

Adhesive must be stored above 60°, but below 120°F. In cold weather, store off floor in a heated area. Do not store in direct sun or at consistently high temperatures as container may burst.