




advanced FLOW engineering™
 P.O. Box 1719
 Corona, CA 92878
 Support: 951-493-7100
 aFepower.com

Intercooler Tube Installation Instructions: 2007.5-2008 Dodge Ram Cummins Intercooler Tube Upgrade L6-6.7L


Kit P/N: 46-20039	Tools Required: 7/16" deep socket 10mm socket or wrench 13mm socket or wrench	Parts list 1 Tube, 3-1/2" x 3" ntercooler upgrade 1 Coupler, hump 3-1/2" 1 Coupler, hump 3" 2 Clamp, spring 3.75" 2 Clamp, spring 3.25" 2 Plug, 1/8" NPT
Make: Dodge		
Model: Year: Engine:		
Ram 2500 '07.5-'08 L6-6.7L(td)		
Ram 3500 '07.5-'08 L6-6.7L(td)		
Ram 4500 '07.5-'08 L6-6.7L(td)		
Sterling Bullet '07.5-'08 L6-6.7L(td)		



Complete Kit w/ Parts




Complete Stock Intercooler tube.




Loosen the four bolts holding in a/c condenser. Pull back passenger side condenser cover.




Pull up condenser only on the driver side.




Using bailing wire or bungee cord, secure condenser to grill.




Loosen the two 10mm screws holding in intercooler on radiator support.



With 7/16" nut driver, loosen clamp on manifold. Push down on intercooler tube and disconnect from manifold.




With 7/16" nut driver, loosen clamp on intercooler.



Pull back coupler from intercooler.




Remove stock intercooler tube from vehicle.




Install 3-1/2" hump coupler to manifold with clamps provided.




Install new tube and position into coupler on manifold.




Install 3" hump coupler with clamps provided to new tube and position onto intercooler.



Re-install intercooler to radiator support. (step 5)
 Re-attach a/c condenser and cover and tighten. (step 2)



Tighten all four clamps. Make sure all clamps are completely tighten. **Check and tighten after 50 miles!**



Your intercooler tube installation is now complete. Please check all clamps periodically and tighten. Thank you for choosing aFe power!