



Magnum Force

Intake System Cover

PN: 54-32578-B/CL

Important!

Please read all instruction steps before you begin installation.

Make	Model	Year	Engine
RAM	1500 EcoDiesel	2014-2016	V6-3.0L (td)

Step 1. Remove trim seal from housing.

Step 2. Slide cover down on housing as shown.

Step 3. Install the provided (3) M6 screws in place.

Your installation is now complete!



advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com

06-80675