



**XDP 2007.5-2009 Cummins Fuel Filter Delete
Item Number: XD241**

PACKING LIST:

- 1 – XDP Fuel Filter Delete Block
- 4 – Copper Banjo Bolt Washers



Before removing any parts from your truck, please read over the install steps and verify you have everything necessary to install your XDP 2007.5-2009 Cummins Fuel Filter Delete.



Ensure that the vehicle has not been in use and that the engine is cool to the touch. Always wear eye protection when working on any vehicle.

****The front port (below the XDP logo) is used as a return for on applications equipped with dual CP3's.****

Step 1: Gain access to the fuel filter assembly by either removing the intake horn on top of the engine or the driver side front fender well.

Step 2: Locate the drain valve and drain hose to the left side of the fuel filter assembly.

Step 3: Loosen the fuel filter cap and open the valve to drain the fuel to a safe location.

Step 4: Disconnect the two sensors from the front of the fuel filter assembly.

Step 5: Remove the fuel lines connected to the fuel filter assembly along with the support brackets.

Step 6: Remove the fuel filter assembly from the engine.

Step 7: Remove the WIF sensor from the filter assembly and install this in the bottom of the filter delete block.

Step 8: Using the factory bolts, loosely install the filter delete block onto the engine where the filter assembly was located.

Step 9: Install the factory banjo bolts and fuel lines to the filter delete block using the supplied copper banjo washers.

Step 10: Tighten the bolts securing the filter delete block to the engine and torque the banjo bolts to factory specs.



1-888-DIESEL4 – 1-888-343-7354

WWW.XDP.COM