



XDP Billet Turbo Resonator Delete Plug XD184

Item Number: XD184

PACKING LIST:

1 – Billet Resonator Delete Plug
w/ O-Ring



Before removing any parts from your truck, please compare the items you have received with the packing list provided to verify that you have everything necessary to install your new XDP Billet Turbo Resonator Delete Plug.

Ensure that the vehicle has not been in use and that the engine is cool to the touch. ALWAYS wear eye protection when working on any vehicle

*** PLEASE READ INSTRUCTIONS PRIOR TO INSTALLATION ***

Step 1: Disconnect Batteries

Step 2: Locate your OE resonator under your hood. (Figure A)

Step 3: Remove all mounting screws/fasteners holding the resonator in place. Using a rocking motion, lift and remove the resonator plenum from the intake tube. (Figure B)

Step 4: Position the XDP Billet Turbo Resonator Delete Plug over the opening in your intake tube and press firmly using the palm of your hand to seat the plug into place. (Figure C)

