



XDP Billet PCV Re-Route Plug

Item Number: XD185

PACKING LIST:

1 – Billet PCV Re-Route Plug w/ O-Ring



Before removing any parts from your truck, please compare the items you have received with the packing list provided to verify that you have everything necessary to install your new XDP Billet PCV Re-Route Plug.



Ensure that the vehicle has not been in use and that the engine is cool to the touch. ALWAYS wear eye protection when working on any vehicle.

*** PLEASE READ INSTRUCTIONS PRIOR TO INSTALLATION ***

Step 1: Disconnect Batteries

Step 2: Locate your OE resonator under your hood. (Figure A)

Step 3: Remove all mounting screws/fasteners holding the resonator in place. Using a rocking motion, lift and remove the resonator plenum from the intake tube. (Figure B)

Step 4: Unclip the PCV crossover tube using pliers to loosen the clamp. (Figure C)

Step 5: Disconnect the PCV line from the intake tube. (Figure D)

Step 6: Install the XDP Billet PCV Re-Route Plug by pressing firmly down with the palm of your hand.

Step 7: Re-route your PCV using your own preference.

