

14885 Monte Vista Avenue Chino, Ca. 91710 888.360.3696

Description: Head Light



Read complete instructions before installation! Improper installation may void warranty



Tools needed: 10 mm socket, electrical tape, wire splicer, flat head screw driver.



Step 3: Use the 10 mm socket to remove the last nut holding in the head light.



Step 5: Remove the head light from the vehicle.



Step 8: Take out the new Anzo head light from the box.



Step 1: Use the 10 mm socket to remove the two screws holding the headlight to the frame.



Step 4: Use the flat head screw driver with a cloth to remove the head light if you are not able to pull off the head light from the vehicle.



Step 6: Twist off the corner parking light.



Step 9: (A)Please note if your vehicle is 2006 you will use the L connector for the halos. (B) If you have 2007-08 you will use the two loose wires.



Step 2: Remove the rubber cover located in the wheel well.





Step 7: Unplug the head light wire harness.



Step 10: For 2007-2008 trucks you will have to splice the halos. Pull back the cover to expose the wires on the corner parking light.



Step 11: Splice the blue wire into the middle white/green wire and the black to the black wire to power the halos.



Step 14: Connect the head light wire harness into the new head light.



Step 12: Remove the protective plastic on the resistor and stick on the back of the new Anzo head light.



Step 15: Put the new head light into the vehicle and reverse steps to put the light back in.



Step 13: Twist the corner parking into the new head light.



Step 16: Please test all functions making sure they work properly before driving.

AnzoUSA[™] products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA[™] product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.